

IC-F70 Series

256 Channel 5W. Handheld Transceiver. IPX7 Rating, CTCSS, 5-TONE, DTCS, DTMF Encode/Decode *NOTE: Battery Charger to be ordered separately.

VHF F70S Simple Version

VHF F70T Keypad Version (DTMF 10 Keys)

IC-F70T 136MHz to 174MHz Analogue Version

IC-F80S/DS & IC-F80T/DT

256 Channel 4W. Handheld Transceiver. IPX7 Rating, CTCSS, 5-TONE, DTCS, DTMF Encode/Decode *NOTE: Battery Charger to be ordered separately.

UHF F80S/DS Simple Version

IC-F80S-L 400MHz to 470MHz Analogue Version

IC-F80S-H 450MHz to 520MHz Analogue Version

IC-F80DS-L 400MHz to 470MHz P25 Digital Version

IC-F80DS-H 450MHz to 520MHz P25 Digital Version

UHF F80T/DT Keypad Version (DTMF 10 Keys)

IC-F80T-L 400MHz to 470MHz Analogue Version

IC-F80T-H 450MHz to 520MHz Analogue Version

IC-F80DT-L 400MHz to 470MHz P25 Digital Version

IC-F80DT-H 450MHz to 520MHz P25 Digital Version

Chargers

AD110 Charging adaptor sleeve for BP235/236 with BC119N or BC121N

BC119N Single Rapid Charger (Req AD110 for BP235/BP236)

BC121N 6 Way Rapid Charger (Req 6 x AD110 + BC157V or OPC-656)

BC157V 12V/7A Power Supply (for BC121N)

CP17L Cigarette Lighter Cable with Noise Filter for BC119N

OPC-515L DC Power Cable, for use with BC119N

OPC-656 12V DC Lead for BC121N

Batteries

BP237 Battery Case (Takes 6 x AA Cells)

BP-253 Li-ion battery pack, 7.4V/1650mAh

BP-254/FM Li-ion battery pack, 7.4V.3040mAh (For IS models)

Remote Audio Options (Note: Headset are not Waterproof)

HM138 Speaker Microphone, Waterproof

HS94 Headset, ear-piece type

HS95 Behind-the Head Headset. Req VS1L

HS97 Throat Microphone. Req VS1L

VS1SC VOX PTT for HS94, HS95, HS97, 90 degree entry

Analogue Plug Option Boards

UT111 LTR Trunking Board

UT109#02 Voice Scrambler Frequency Inversion Type

UT110#02 Voice Scrambler Rolling Code Type

Digital Up-grade / Encryption Software

UT120#01	DSP Unit for IC-F70/F80
FS-F70/F1700	Flash Loader
EX2785J01	P25 Activation Key, (Required for UT120 Up-grade)
EX2785J02	DES Activation Key, (Digital Option)
EX2785J03	AES Activation Key, (Digital Option)
OPC-1558	Key Loader Cable for Handheld radio

the radio.

The OPC-1558 Cable provides the Inter-face connection between the KVL-3000 Loader & the Icom radio. (This strategy is employed to keep security in the field to a maximum at all times)

Spare Antenna

FA-SC25V	VHF flexible antenna, 136-150MHz
FASC55V	VHF Flexible Antenna (146-174MHz Band) (Red)*
FASC56VS	VHF Stubby Antenna (150-160MHz Band) (Red)*
FASC57VS	VHF Stubby Antenna (160-174MHz Band) (Green)
FASC25U	UHF Flexible Antenna (403-430MHz Band) (Green)*
FASC57U	UHF Flexible Antenna (430-470MHz Band) (Red)*
FASC61UC	UHF Cut Type Antenna, 380-520MHz
FASC61VC	VHF Cut Type Antenna, 136-174MHz
FASC72U	UHF Flexible Antenna (470-500MHz Band) (Blue)*
FASC73US	UHF Stubby Antenna (450-490MHz Band)
AD98FSC	Antenna Connector Adapter (For BNC-J Type Antenna)

Programming Equipment

CS-F70/F1700	Dealer Programming Software Req OPC-966
OPC-966	Programming Cable (PC-->Tr) Req CS-F70 Software
OPC-966U	RS232 USB Programming Cable
500	Programming Fee (Please refer to page 5)

Belt clips

MB93	Swivel Belt clip
MB94	Belt-Clip Alligator Type (same type as supplied)
MB96F	Fixed type belt hanger for MB94
MB-96N	Swivel type belt hanger

Carry Case

LCF80HSBEE	H/Duty Leather case with Clip
------------	-------------------------------